



Hinweis:
Rote LED An = Störung
Grüne LED An = Freigabe erteilt

LED Anzeige Logik				
Klemme 6	10V	10V	0V	0V
Klemme 7	0V	10V	10V	0V
LED Anzeige	rot (1)	grün (2)	—	—

notice:
red LED On = fault signal
green LED On = unblocking

note:
LED rouge = défaut
LED verte = autorisation de marche

LED display logic				
terminal 6	10V	10V	0V	0V
terminal 7	0V	10V	10V	0V
LED display	red (1)	green (2)	—	—

LED indicateur logique				
borne 6	10V	10V	0V	0V
borne 7	0V	10V	10V	0V
LED indicateur	rouge (1)	vert (2)	—	—