



		Maße (mm)																				
Art.-Nr.	Type	A	B	C	E	F	N	O	P	R	S	T	U	V	W	Y	Z	AA	AB	AC	AE	AF
04254	AIR1-KR KW XH 1000 R	1000	490	635	715	312	370	318	215	343	238	315	210	-	-	189	40	82	317	G 1/2	858	587
04255	AIR1-KR KW XH 1500 R	1000	570	642	795	312	370	323	265	378	338	350	310	-	-	185	47	82	399	G 3/4	858	594
04264	AIR1-KR KW XH 2500 R	1000	620	862	845	312	370	433	300	498	338	470	310	-	-	189	38	86	439	G 3/4	858	814
04268	AIR1-KR KW XH 3500 R	1100	670	967	895	312	470	484	340	608	438	580	410	-	-	187	43	88	485	G 1	958	919
04278	AIR1-KR KW XH 4500 R	1100	870	1020	1095	312	470	510	452	608	438	580	410	-	-	184	50	98	666	G 1 1/4	958	969
04279	AIR1-KR KW XH 5500 R	1100	870	1230	1095	312	470	615	452	883	438	855	410	498	-	193	67	94	674	G 1 1/4	958	1179
04281	AIR1-KR KW XH 7000 R	1100	870	1530	1095	312	470	765	427	1083	438	1055	410	498	361,1	193	67	94	674	G 1 1/2	958	1479
04282	AIR1-KR KW XH 8500 R	1100	870	1880	1095	312	470	940	427	1228	438	1200	410	498	409,4	193	67	98	666	G 1 1/2	958	1829