


EC 100/60 F SS-1175



3	100 m <sup>3</sup> /h			
2	60 m <sup>3</sup> /h			
1				

a) manuell Ein  
b) Automatik deaktivieren

a) ON manually  
b) deactivate automatic

a) Mode manuel forcé  
b) Désactivation du mode automatique