


RHS 3 + 1



Hilfskontakt
Auxillary contact
Contact auxiliaire

2 / T1 - 1 / L1
4 / T2 - 3 / L2
6 / T3 - 5 / L3

N N