



| DIP-Schalter | | |
|--------------|------------------------|------------------|
| DIP 2 | DIP 1 | VOC-Sensibilität |
| OFF | OFF | Gering |
| OFF | ON | Medium (default) |
| OFF | ON | Hoch |
| DIP 3 | VOC-Nullpunktautomatik | |
| ON | aktiviert (default) | |
| OFF | deaktiviert | |

| DIP 4 | Ausgang |
|-----------|-----------------------------|
| ON | nicht verwendet |
| OFF | Spannung 0 - 10 V (default) |
| DIP 5 | intern |
| ON | nicht verwendet |
| OFF | default |



| DIP switch | | |
|------------|--------------------------|------------------|
| DIP 2 | DIP 1 | VOC-Sensitivity |
| OFF | OFF | Low |
| OFF | ON | Medium (default) |
| OFF | ON | High |
| DIP 3 | VOC zero point automatic | |
| ON | activated (default) | |
| OFF | deactivated | |

| DIP 4 | Output |
|-----------|----------------------------|
| ON | not used |
| OFF | voltage 0 - 10 V (default) |
| DIP 5 | internal |
| ON | not used |
| OFF | default |



| Interrupteur DIP | | |
|------------------|-----------------------------------|----------------------------|
| <i>DIP 2</i> | <i>DIP 1</i> | <i>Sensibilité aux VOC</i> |
| OFF | OFF | Faible |
| OFF | ON | Medium (par défaut) |
| OFF | ON | Haut |
| <i>DIP 3</i> | <i>Point zéro VOC automatique</i> | |
| ON | activé (par défaut) | |
| OFF | désactivé | |

| <i>DIP 4</i> | <i>Sortie</i> |
|--------------|-------------------------------|
| ON | non utilisé |
| OFF | Tension 0 - 10 V (par défaut) |
| <i>DIP 5</i> | interne |
| ON | non utilisé |
| OFF | par défaut |